



Retouch Crayons

- For filling and masking superficial scratches on finished wood
- Expand and contract with the wood
- Do not shrink or drop out
- Easy rub on and buff off application
- Wide range of colours available



Product use

Liberon Retouch Crayons can be used to fill scratches, nail holes, worm holes etc. in furniture and other woodwork.

Application

Rub the crayon across the scratch until it is filled, allow to harden then buff off the excess with a cotton cloth.

Important: Always test product on a spare surface or inconspicuous area for colour, compatibility and end result.

Colours

Pine, Kitchen, Mahogany, Oak, Walnut and Mixed.

Packaging

Retouch Crayons are available in Pine, Mahogany, Oak, Walnut and Mixed.